OnePak 4 -21G (Article number: BC000408)

[va-Q-one 4 -21G]

For -25 °C to -15 °C shipments





Product picture shows an exemplary solution for the temperature range +2 °C to +8 °C

DESCRIPTION

Specifically designed for door-to-door pharmaceutical distribution of smaller volumes to remote locations, OnePak ensures your products reach even the most inaccessible areas without compromising quality or efficacy. This single-use solution is ideal for regions with limited logistics services, eliminating the need for return shipping and ensuring consistent access to medicines.

Date: 2024-08-21 Page: 1 of 2 Version: 14393

OnePak 4 -21G (Article number: BC000408)

[va-Q-one 4 -21G]

For -25 °C to -15 °C shipments



DIMENSIONS AND WEIGHT

External Dimensions (1 x w x h)		Internal Dimensi	ons ¹ (1 x w x h)	Tolerances	
[mm]	[inch]	[mm]	[inch]	[mm]	[inch]
360 x 345 x 370	14.2 x 13.6 x 14.6	165 x 165 x 165	6.5 x 6.5 x 6.5	± 5	± 0.2

Tare W	eight ¹	Payload ¹ (Volume)	
[kg]	[lbs]	[L]	
12.4 ± 1	27.3 ± 2.2	4	

¹including Temperature Batteries

TEMPERATURE BATTERY CONFIGURATION

OneBlok	Pieces	Dimensions ² (1 x w x h)		Weight		Material number
		[mm]	[inch]	[kg]	[lbs]	Hatchial Hamber
20204 -21G	6	200 x 200 x 39	7.9 x 7.9 x 1.5	1.6	3.5	AK000248

²dimensions of empty Temperature Battery shell, variation due to PCM inside and aggregation state possible

PERFORMANCE The OnePak 4 -21G is qualified in the temperature range from -25 °C to -15 °C

Temperature scenario	Duration [hrs]	Kelvin-hours ³	Average ambient temperature [°C]
ISTA 7D summer	≥ 115	≥ 5773	+30.2

³Detailed information about the concept of Kelvin-hours on www.kelvinhours.com

For more details, please view the qualification report. Before performing a shipment with the OnePak 4 -21G it is suggested that the user performs a validation process with the equipment available and under the conditions available. A test in worst case conditions is recommended. The box provides a very stable and well-designed system solution which has to be adapted on the particular requirements of the user.

For more information please contact support@envirotainer.com.

Date: 2024-08-21 Page: 2 of 2 Version: 14393