

# ProofTainer Case -26G

[va-Q-case 1/2 Euro -26G]

For -20 °C shipments

# Envirotainer°

Precision with Purpose



Product picture shows an exemplary solution without temperature batteries

## DESCRIPTION

Delivering superior performance while streamlining handling, the ProofTainer family features six sizes, accommodating from 0.5 – 2 EU or 1 - 2 US pallets. Whether you're shipping clinical trials or commercial drugs, we ensure consistent temperature control throughout your products journey. With qualified temperature ranges from -70°C to +20°C and over 120 hours of autonomy, ProofTainer provides optimal conditions for your sensitive cargo, delivering the flexibility you need for your product requirements.

## DIMENSIONS AND WEIGHT

External Dimensions (l x w x h)		Internal Dimensions <sup>1</sup> (l x w x h)		Tolerances	
[mm]	[inch]	[mm]	[inch]	[mm]	[inch]
800 x 600 x 800	31.5 x 23.6 x 31.5	610 x 356 x 470	24 x 14 x 18.5	± 5	± 0.2

Tare Weight <sup>1</sup>		Volumetric weight		Maximum Payload (Weight)		Payload <sup>1</sup> (Volume)
[kg]	[lbs]	[kg]	[lbs]	[kg]	[lbs]	[L]
145 ± 15	319.7 ± 33.1	64	141.1	100	220.5	96

<sup>1</sup>Including Temperature Batteries

## TEMPERATURE BATTERY CONFIGURATION

ProofBlok	Pieces	Dimensions <sup>2</sup> (l x w x h)		Weight		Material number
		[mm]	[inch]	[kg]	[lbs]	
27L -26G	18	470 x 275 x 32	18.5 x 10.8 x 1.3	4.5	9.9	AK000096

<sup>2</sup>dimensions of empty Temperature Battery shell, variation due to PCM inside and aggregation state possible

## PERFORMANCE The ProofTainer Case -26G is qualified in the temperature range below -20 °C

Temperature scenario	Duration [hrs]	Kelvin-hours <sup>3</sup>	Average ambient temperature [°C]
controlled summer	> 144	> 6480	+20
extreme summer	120	n.a.	+49.9

<sup>3</sup>Detailed information about the concept of Kelvin-hours on [www.kelvinhours.com](http://www.kelvinhours.com)

For more details, please view the qualification report. Before performing a shipment with the ProofTainer Case -26G it is suggested that the user performs a validation process with the equipment available and under the conditions available. A test in worst case conditions is recommended. The box provides a very stable and well-designed system solution which has to be adapted on the particular requirements of the user.

For more information please contact [support@envirotainer.com](mailto:support@envirotainer.com).