



Product picture shows an exemplary solution for the temperature range +2 °C to +8 °C

## DESCRIPTION

Specifically designed for door-to-door pharmaceutical distribution of smaller volumes to remote locations, OnePak ensures your products reach even the most inaccessible areas without compromising quality or efficacy. This single-use solution is ideal for regions with limited logistics services, eliminating the need for return shipping and ensuring consistent access to medicines.



## **DIMENSIONS AND WEIGHT**

External Dimens	ions (l x w x h)	Internal Dimensi	ons <sup>1</sup> (l x w x h)	Tolerances	
[ mm ]	[inch]	[ mm ]	[inch]	[ mm ]	[inch]
1200 x 800 x 820	47.2 x 31.5 x 32.3	1005 x 625 x 475	39.6 x 24.6 x 18.7	± 5	± 0.2
			•		

Tare W	/eight <sup>1</sup>	Payload <sup>1</sup> (Volume)		
[kg]	[lbs]	[L]		
93.9 ± 2	207 ± 4.4	298		

<sup>1</sup>including Temperature Batteries

## **TEMPERATURE BATTERY CONFIGURATION**

OneBlok		Pieces	Dimensions <sup>2</sup> (l x w x h)		Weight		Material number
	Oliebiok Fieces	[ mm ]	[inch]	[kg]	[lbs]	Hateriar Humber	
	34242 -21G	20	335 x 243 x 19	13.2 x 9.6 x 0.7	1.7	3.7	AK000250
	44342 -21G	8	435 x 335 x 19	17.1 × 13.2 × 0.7	3	6.6	AK000251

<sup>2</sup>dimensions of empty Temperature Battery shell, variation due to PCM inside and aggregation state possible

## **PERFORMANCE** The OnePak 300 -21G is qualified in the temperature range from -25 $^{\circ}$ C to -15 $^{\circ}$ C

Temperature scenario	Duration [hrs]	Kelvin-hours <sup>3</sup>	Average ambient temperature [°C]	
ISTA 7D summer	≥ 102	≥ 5059	+29.6	

<sup>3</sup>Detailed information about the concept of Kelvin-hours on www.kelvinhours.com

For more details, please view the qualification report. Before performing a shipment with the OnePak 300 -21G it is suggested that the user performs a validation process with the equipment available and under the conditions available. A test in worst case conditions is recommended. The box provides a very stable and well-designed system solution which has to be adapted on the particular requirements of the user.

For more information please contact support@envirotainer.com.