OnePak 8 +05G EL (Article number: BC000720)

[va-Q-one 8 +05G EL]

For +2 °C to +8 °C shipments





Product picture shows an exemplary solution for the temperature range +2 °C to +8 °C

DESCRIPTION

Specifically designed for door-to-door pharmaceutical distribution of smaller volumes to remote locations, OnePak ensures your products reach even the most inaccessible areas without compromising quality or efficacy. This single-use solution is ideal for regions with limited logistics services, eliminating the need for return shipping and ensuring consistent access to medicines.

Date: 2025-04-22 Page: 1 of 2 Version: 15335

OnePak 8 +05G EL (Article number: BC000720)

[va-Q-one 8 +05G EL]

For +2 °C to +8 °C shipments



DIMENSIONS AND WEIGHT

External Dimensions (1 x w x h)		Internal Dimensi	.ons 1 (1 x w x h)	Tolerances	
[mm]	[inch]	[mm]	[inch]	[mm]	[inch]
380 x 360 x 375	15 x 14.2 x 14.8	200 x 200 x 200	7.9 x 7.9 x 7.9	± 5	± 0.2

Tare W	eight ¹	Payload ¹ (Volume)		
[kg]	[lbs]	[L]		
9 ± 1	19.8 ± 2.2	8		

¹including Temperature Batteries

TEMPERATURE BATTERY CONFIGURATION

OneBlok Pieces	Pieces	Dimensions ² (1 x w x h)		Weight		Material number
		[mm]	[inch]	[kg]	[lbs]	
23233 +05G EL	6	225 x 225 x 29	8.9 x 8.9 x 1.1	1	2.2	AK000449

²dimensions of empty Temperature Battery shell, variation due to PCM inside and aggregation state possible

PERFORMANCE The OnePak 8 +05G EL is qualified in the temperature range from +2 °C to +8 °C

Temperature scenario	Duration [hrs]	Kelvin-hours ³	Average ambient temperature [°C]
ISTA 7D summer	≥ 114	≥ 2793	+29.5
ISTA 7D winter	> 144	n.a.	+5

³Detailed information about the concept of Kelvin-hours on www.kelvinhours.com

For more details, please view the qualification report. Before performing a shipment with the OnePak 8 +05G EL it is suggested that the user performs a validation process with the equipment available and under the conditions available. A test in worst case conditions is recommended. The box provides a very stable and well-designed system solution which has to be adapted on the particular requirements of the user.

For more information please contact support@envirotainer.com.