



Product picture shows an exemplary solution for the temperature range +2 °C to +8 °C

DESCRIPTION

Ensure patient-safe medicines and accurate clinical trial results with ProofPak. Our innovative, reusable thermal packaging ensures precise temperature control from -70°C to +37°C, unaffected by seasons or climate. Qualified according to ISTA 7D standards, ProofPak ensures consistent reliability, safeguarding your temperature-sensitive pharmaceuticals from production through to delivery. Experience seamless logistics with 'ready to load & go', giving you time to focus on advancing your clinical research while we protect your products with unmatched precision and reliability.

Note: This product shall be stored and transported in upright position!

DIMENSIONS AND WEIGHT

External Dimensions (l x w x h)		Internal Dimensions ¹ (l x w x h)		Tolerances	
[mm]	[inch]	[mm]	[inch]	[mm]	[inch]
555 x 560 x 555	21.9 x 22 x 21.9	420 x 420 x 420	16.5 x 16.5 x 16.5	± 5	± 0.2
Tare Weight ¹			Payload ¹ (Volume)		
[kg]	[lbs]		[L]		
31 ± 1	68.3 ± 2.2		74		

¹Including Temperature Batteries

TEMPERATURE BATTERY CONFIGURATION

ProofBlok	Pieces	Dimensions ² (l x w x h)		Weight		Material number
		[mm]	[inch]	[kg]	[lbs]	
46462 +22G	6	455 x 455 x 20	17.9 x 17.9 x 0.8	3.2	7.1	AK000160

²dimensions of empty Temperature Battery shell, variation due to PCM inside and aggregation state possible

PERFORMANCE The ProofPak 74 Standard +22G is qualified in the temperature range from +15 °C to +25 °C

Temperature scenario	Duration [hrs]	Kelvin-hours ³	Average ambient temperature [°C]
ISTA 7D summer	> 144	> 1411	+29.8
ISTA 7D winter	≥ 95	≤ -1435	+4.9

³Detailed information about the concept of Kelvin-hours on www.kelvinhours.com

For more details, please view the qualification report. Before performing a shipment with the ProofPak 74 Standard +22G it is suggested that the user performs a validation process with the equipment available and under the conditions available. A test in worst case conditions is recommended. The box provides a very stable and well-designed system solution which has to be adapted on the particular requirements of the user.

For more information please contact support@envirotainer.com.